



Crystalfontz America, Incorporated

CFA920-TS User Guide



CFAF480800T07-043T-TS TFT display shown with CFA10057 mother board. Included CFA10036 not shown.

CFA920-TS is an assembled product that contains:

- [CFA10036](#) SOM (System On Module)
- CFA10057 Mother Board
- [CFAF480800T07-043T-TS](#) TFT Display

CFA920-TS User Guide Release 2013-08-02
for

CFA920-TS Hardware Version: v1.0

Crystalfontz America, Incorporated

12412 East Saltese Avenue
Spokane Valley, WA 99216-0357

Phone: 888-206-9720

Fax: 509-892-1203

Email: support@crystalfontz.com

URL: www.crystalfontz.com



CFA920-TS Data Sheet Revision History

Release Date: 2013-08-02

- Added information about our TTL-to-USB converter to use on the CFA10036 SOM (System On Module). See [USB633 TTL-To-USB Converter \(Pg. 7\)](#).
- Added a link to the CFA10036's processor data sheet for electrical characteristics. See [ELECTRICAL CHARACTERISTICS \(Pg. 7\)](#).
- Corrected USB label in photo. See [CFA10036 SOM Mounted On Back Of CFA10057 Mother Board \(Pg. 6\)](#).
- Added approximate overall dimensions and weight. See [PHYSICAL CHARACTERISTICS \(Pg. 7\)](#).
- Added table with descriptions of the 30 pins for J_EXP. See [30-Pin Expansion Connector J_EXP \(Pg. 10\)](#).

Release Date: 2013-04-26

New *CFA920-TS User Guide*.

Hardware and Firmware Revisions

For information about hardware revisions, see the Part Change Notifications (PCNs) under the "Notices" tab on the [CFA920-TS](#) web page.

About Variations

We work continuously to improve our products. Because display technologies are quickly evolving, these products may have component or process changes. Slight variations (for example, contrast, color, or intensity) between lots are normal. If you need the highest consistency, whenever possible, order and arrange delivery for your production runs at one time so your displays will be from the same lot.



The Fine Print

Certain applications using CrystalFontz America, Inc. products may involve potential risks of death, personal injury, or severe property or environmental damage ("Critical Applications"). CRYSTALFONTZ AMERICA, INC. PRODUCTS ARE NOT DESIGNED, INTENDED, AUTHORIZED, OR WARRANTED TO BE SUITABLE FOR USE IN LIFE-SUPPORT APPLICATIONS, DEVICES OR SYSTEMS OR OTHER CRITICAL APPLICATIONS. Inclusion of CrystalFontz America, Inc. products in such applications is understood to be fully at the risk of the customer. In order to minimize risks associated with customer applications, adequate design and operating safeguards should be provided by the customer to minimize inherent or procedural hazard. Please contact us if you have any questions concerning potential risk applications.

CrystalFontz America, Inc. assumes no liability for applications assistance, customer product design, software performance, or infringements of patents or services described herein. Nor does CrystalFontz America, Inc. warrant or represent that any license, either express or implied, is granted under any patent right, copyright, or other intellectual property right of CrystalFontz America, Inc. covering or relating to any combination, machine, or process in which our products or services might be or are used.

All specifications in Data Sheets and on our website are, to the best of our knowledge, accurate but not guaranteed. Corrections to specifications are made as any inaccuracies are discovered.

Company and product names mentioned in this publication are trademarks or registered trademarks of their respective owners.

Copyright © 2013 by CrystalFontz America, Inc., 12412 East Saltese Avenue, Spokane Valley, WA 99216-0357 U.S.A.

Special Terms Applicable for the CFA920-TS Designated as NOT FCC Approved / FCC NOTICE

The CFA920-TS has NOT been authorized under the rules of the Federal Communications Commission and may not be offered for further sale or lease, or sold or leased, until authorization is obtained. FCC experimental licensing requirements may apply to Buyer's use.

The CFA920-TS is made available solely to allow product developers to evaluate CrystalFontz technology and/or software associated with the CFA920-TS to determine whether to incorporate such items in a finished product. This is not a finished product and when assembled may not be resold or otherwise marketed unless all required FCC equipment authorizations are first obtained. Operation is subject to the conditions that this CFA920-TS not cause harmful interference to licensed radio stations and that this CFA920-TS accept harmful interference. Unless the assembled kit is designed to operate under Part 15 or Part 95 of the FCC Rules, the operator of the kit must operate under the authority of an FCC license holder or must secure an experimental authorization under Part 5 of the FCC Rules.

This CFA920-TS is not an end product or finished appliance and is not intended or authorized to be integrated into end products as is. Buyer may use the CFA920-TS to create prototypes for its own internal experimental use, and may add components, features, software and/or functionality, in the process of designing its own final products. Buyer shall only assign technically qualified electronics experts who are familiar with the dangers and application risks associated with handling electrical mechanical components, subsystems and systems to use the CFA920-TS, and that such use takes place solely in laboratory/development environments (and not in residential environments). The Non-FCC approved CFA920-TS is FOR ENGINEERING DEVELOPMENT, DEMONSTRATION, AND/OR EVALUATION PURPOSES ONLY.



CONTENTS


INTRODUCTION	5
ACCESSORIES	6
PHYSICAL CHARACTERISTICS	7
ELECTRICAL CHARACTERISTICS	7
ABOUT ESD	7
PIN TABLES	8
120-Pin Expansion Debug Connector	8
30-Pin Expansion Connector J_EXP	10
CARE AND HANDLING PRECAUTIONS	11

Preliminary



INTRODUCTION

CFA920-TS is an assembled product that contains the three parts described below. Software support is already built into the Linux mainline kernel.



❑ CFA10057 Mother Board

The CFA920-TS is shipped with our CFAF480800T07-043T-TS TFT display mounted on top of the CFA10057 mother board and the CFA10036 SOM (System On Module) mounted on the back of the mother board. The mother board is only a few millimeters larger than the display. The CFA10036 is smaller than the motherboard.

Pin descriptions for the CFA10057 are included in this User Guide.



❑ CFA10036 SOM (System On Module)

The CFA10036 is a small, highly functional ARM9-based Linux SOM (System On Module) shipped with a full Linux operating system. Because a full Linux mainline kernel is already ported to the CFA10036, you can devote your resources to applications in the languages of your choice. It is low cost, easy to use, and has lots of GPIO. The CFA10036 in this assembled CFA920-TS has an i.MX283 processor. Please refer to the [Freescale i.MX28 Data Sheet](#) for more information on the processor. For more information on the CFA10036, see the documents listed under the [Doc/Files](#) tab on the CFA920-TS web page.

Blind threaded SMT standoffs hold the CFA10036 SOM securely to the back of the CFA10057 mother board.



❑ CFAF480800T07-043T-TS TFT Display

The CFAF480800T07-043T-TS is a 480 x 800 full color touch screen display. The active area is 4.3-inches diagonal. Supply voltage is 3.3v. For more information, see the [CFAF480800T07-043T-TS Data Sheet](#) listed under the [Doc/Files](#) tab on the CFAF480800T07-043T-TS web page.

The TFT is connected to the CFA10057 by its FPC.




Figure 1. CFA10036 SOM Mounted On Back Of CFA10057 Mother Board

ACCESSORIES

CFAL12832D-B



The optional [CFAL12832D-B](#) can be mounted onto the CFA10036 with its ZIF connector. This 128x32 OLED graphics module displays light (near-white) characters on a dark (near-black) background. Less than 0.5-inch high (11.5 mm), the OLED is useful for status messages and debugging.

CFA10040PWR




The [CFA10040PWR](#) is a 110 VAC +5v wall power supply that can be used to power the CFA10057 mother board. Cord length is ~63 inches.



WR-USB-Y03 Cable

The [WR-USB-Y03](#) is about 6-feet long. This cable has two different types of USB connectors, one smaller than the other. Connect the cable's smaller 2 mm female USB connector to the CFA10057's USB connector. Connect the cable's larger USB-A female connector to your host's USB-A connector.



USB633 TTL-To-USB Converter

You can connect the [USB633](#) to the dedicated DUART on the CFA10036 SOM (System On Module). Pins 2 through 5 on the USB633 need to be connected to pins 1 through 4 on the CFA10036.

PHYSICAL CHARACTERISTICS

Specifications	
Overall Dimensions	Approximately 108 (W) x 63 (H) millimeters
Weight	Approximately 106 grams
Operating Temperature	-20°C to +70°C
Humidity (RH noncondensing)	90%

ELECTRICAL CHARACTERISTICS

For electrical characteristics on the CFA10036's processor, please see the [i.MX28 Data Sheet](#).

ABOUT ESD

The circuitry is industry standard CMOS logic and is susceptible to ESD damage. Please use industry standard antistatic precautions as you would for any other static sensitive devices such as expansion cards, motherboards, or integrated circuits. Ground your body, work surfaces, and equipment.



PIN TABLES

120-PIN EXPANSION DEBUG CONNECTOR

The [SAMTEC FSI-130-10-L-D-AD](#) connector can be used to connect to the CFA10057's J_DBG1 and J_DBG2 expansion ports.

DBG1

DBG1 Connector	Pin	Signal
1	G06	P3.21
2	G07	P3.20
3	K08	P3.18
4	L07	P3.17
5	K07	P3.16
6	B14	HSADC0
7	C14	LRADC6
8	D15	LRADC5
9	D13	LARDC4
10	D09	LRADC3
11	C08	LARDC2
12	C09	LRAC1
13	VDD_+3.3V	
14	GND	
15	C15	LARDC0
16	(A11)	PSWITCH_RAW
17	(A14)	RESET_RAW
18	E14	P4.20
19	B09	DEBUG
20	D14	JTAG_TRST
21	E13	JTAG_TDO
22	E12	JTAG_TDI
23	E11	JTAG_TCK
24	D12	JTAG_TMS
25	U06	P0.06
26	R07	P0.05
27	T07	P0.04
28	U07	P0.03
29	DCDC_BATTERY	
30	GND	

DBG1 Connector	Pin	Signal
31	R08	P0.02
32	T08	P0.01
33	U08	P0.00
34	L08	P0.23
35	M08	P0.22
36	N08	P.021
37	N06	P0.20
38	M09	P0.19
39	M07	P0.18
40	N09	P0.17
41	N07	P0.16
42	K06	P3.15
43	L06	P3.14
44	L05	P3.13
45	M05	P3.12
46	H07	P3.11
47	VDD_+3.3V	
48	GND	
49	H06	P3.10
50	F05	P3.09
51	F06	P3.08
52	L09	P0.28
53	P07	P0.27
54	P06	P0.26
55	P08	P0.25
56	R06	P0.24
57	N05	P1.31
58	N01	P1.30
59	M01	P1.29
60	L01	P1.28



DBG2

DBG2 Connector	Pin	Signal
1	E02	P4.16
2	F02	P4.08
3	F01	P4.07
4	F04	P4.06
5	H02	P4.04
6	H01	P4.03
7	E04	P4.02
8	H04	P4.01
9	G04	P4.00
10	J03	P4.15
11	J04	P4.14
12	F03	P4.13
13	VDD_+5V	
14	GND	
15	G02	P4.12
16	G01	P4.11
17	J02	P4.10
18	J01	P4.09
19	E03	P4.05
20	J05	P3.07
21	K05	P3.06
22	K04	P3.05
23	L04	P3.04
24	J07	P3.03
25	J06	P3.02
26	H05	P3.01
27	G05	P3.00
28	D02	P2.27
29	DCDC_BATTERY	
30	GND	

DBG2 Connector	Pin	Signal
31	B02	P2.026
32	C02	P2.25
33	A02	P2.24
34	C04	P2.19
35	B03	P2.18
36	C03	P2.17
37	A03	P2.16
38	E01	P2.15
39	D01	P2.14
40	C01	P2.13
41	B01	P2.12
42	A06	P2.10
43	D10	P2.09
44	A04	P2.08
45	B04	P2.07
46	D05	P2.06
47	VDD_+3.3V	
48	GND	
49	C05	P2.05
50	A05	P2.03
51	D06	P2.02
52	C06	P2.01
53	B06	P2.00
54	M06	P3.30
55	D07	P3.27
56	E08	P3.26
57	D08	P3.25
58	C07	P3.24
59	E07	P3.23
60	F07	P3.22



30-PIN EXPANSION CONNECTOR J_EXP

Definitions for the devices by default in the i.MX28 processor are here:

`output/build/linux-dd2373e5/arch/arm/boot/dts/imx28.dtsi.`

Definitions for the devices included in the default build for the CFA920-TS (may need to refer to `imx28.dtsi`) are here:

`output/build/linux-dd2373e5/arch/arm/boot/dts/imx28-cfa10057.dts`

Documentation for the 4-digit hexadecimal pin muxes found in the above files are here, referenced from the buildroot folder:

`output/build/linux-dd2373e5/Documentation/devicetree/bindings/pinctrl/fsl,mxs-pinctrl.txt`

Connector	Pin	Signal	MUX0	MUX1	MUX2	Jumper
1	3.3V					
3	A3	P2.16	SSP2_SCK	AUART2_RX	SAIF0_SDATA1	
5	B3	P2.18	SSP2_D0	AUART3_RX	SAIF1_SDATA1	
7	K7	P3.16	PWM_0	I2C1_SCL	DUART_RX	
9	K8	P3.18	PWM_2	USB0_ID	USB1_OC	
11	E7	P3.23	SAIF0_SDATA0	PWM_6	AUART4_TX	
13	P8	P0.25	GPMI_WRN	SSP1_SCK		
15	G6	P3.21	SAIF0_LRCLK	PWM_4	AUART4_RTS	A15:BATT
17	U8	P0.00	GPMI_D0	SSP1_D0		
19	R8	P0.02	GPMI_D2	SSP1_D2		
21	T7	P0.04	GPMI_D4	SSP1_D4		A11:PSWITCH
23	U6	P0.06	GPMI_D6	SSP1_D6		C9LRADC1
25	C7	P3.24	I2C0_SCL	TIMROTA	DUART_RX	
27	N6	P0.20	GPMI_READY0	SSP1_CD	USB0_ID	
29	5.0V					
2	GND					
4	C3	P2.17	SSP2_CMD	AUART2_TX	SAIF0_SDATA2	
6	C4	P2.19	SSP2_D3	AUART3_TX	SAIF1_SDATA2	
8	L7	P3.17	PWM_I	I2C1_SDA	DUART_TX	
10	F7	P3.22	SAIF0_BITCLK	PWM_5	AUART4_RX	
12	E8	P3.26	SAIF1_SDATA0	PWM_7	SAIF0_SDATA1	
14	N8	P0.21	GPMI_READY1	SSP1_CMD		
16	GND					
18	T8	P0.01	GPMI_D1	SSP1_D1		
20	U7	P0.03	GPMI_D3	SSP1_D3		A14:RESET
22	R7	P0.05	GPMI_D5	SSP1_D5		C15:LRADC0
24	T6	P0.07	GPMI_D7	SSP1_D7		C14:LRADC6
26	D8	P3.25	I2C0_SDA	TIMROTB	DUART_TX	
28	G7	P3.20	SAIF0_MCLK	PWM_3	AUART4_CTS	
30	GND					



CARE AND HANDLING PRECAUTIONS

For optimum operation of the CFA920-TS and to prolong its life, please follow the precautions described below.

Note

The care and handling precautions listed below apply to the *CFA10057* mother board and the *CFA10036* SOM in this assembled product.

For the *CFAF480800T07-043T-TS* TFT, see the care and handling in the Data Sheet under the [Doc/Files](#) tab on the display's web page.

ESD (ELECTRO-STATIC DISCHARGE) SPECIFICATIONS

The circuitry is industry standard CMOS logic and is susceptible to ESD damage. Please use industry standard antistatic precautions as you would for any other static sensitive devices such as expansion cards, motherboards, or integrated circuits. Ground your body, work surfaces, and equipment.

DESIGN AND MOUNTING

- Do not disassemble or modify.
- Solder only to the I/O terminals.
- Do not reverse polarity to the power supply connections. Reversing polarity will immediately ruin the product.

AVOID SHOCK, IMPACT, TORQUE, OR TENSION

- Do not expose to strong mechanical shock, impact, torque, or tension.
- Do not drop, toss, bend, or twist.
- Do not place weight or pressure on the product.

OPERATION

- Your circuit should be designed to protect the product from ESD and power supply transients.
- Observe the operating temperature limitations: a minimum of 0°C to a maximum of 50°C noncondensing with minimal fluctuation. Operation outside of these limits may shorten life and/or harm display. Changes in temperature can result in changes in contrast.
 - At lower temperatures.
 - At higher temperature.
- Operate away from dust, moisture, and direct sunlight.

STORAGE AND RECYCLING

- Store in an ESD-approved container away from dust, moisture, and direct sunlight with humidity less than 90% noncondensing.
- Observe the storage temperature limitations: a minimum of -20°C minimum to +80°C noncondensing maximum with minimal fluctuations. Rapid temperature changes can cause moisture to form, resulting in permanent damage.



- Do not allow weight to be placed on the products while they are in storage.
- To discard, please recycle your products at an approved facility.

APPENDIX A: QUALITY ASSURANCE STANDARDS

Note

The quality standards listed below apply to the *CFA10057* mother board and the *CFA10036* SOM in this assembled product.

For the *CFAF480800T07-043T-TS* TFT, see the quality assurance standards in the Data Sheet under the [Doc/Files](#) tab on the display's web page.

INSPECTION CONDITIONS

- Environment
 - Temperature: 25±5°C
 - Humidity: 30~85% RH

ACCEPTANCE SAMPLING

DEFECT TYPE	AQL*
Major	≤.65%
Minor	<1.0%
* Acceptable Quality Level: maximum allowable error rate or variation from standard	

DEFECTS CLASSIFICATION

Defects are defined as:

- A *major defect* is a defect that substantially reduces usability of unit for its intended purpose.
- A *minor defect*: is a defect that is unlikely to reduce usability for its intended purpose.



ACCEPTANCE STANDARDS

#	DEFECT TYPE	ACCEPTANCE STANDARDS CRITERIA	MAJOR/ MINOR
1	PCB defects	<ol style="list-style-type: none">1. Oxidation or contamination on connectors.*2. Wrong parts, missing parts, or parts not in specification.*3. Jumpers set incorrectly.4. Solder (if any) on bezel, LED pad, zebra pad, or screw hole pad is not smooth. <p><i>*Minor if display functions correctly. Major if the display fails.</i></p>	Minor
2	Soldering defects	<ol style="list-style-type: none">1. Unmelted solder paste.2. Cold solder joints, missing solder connections, or oxidation.*3. Solder bridges causing short circuits.*4. Residue or solder balls.5. Solder flux is black or brown. <p><i>*Minor if display functions correctly. Major if the display fails.</i></p>	Minor

Eliminary